


MAGiCARDNEO



TRUSTED, SECURE ID CARD PRINTING


Introducing NEO PrintAnID

Badging software* for the
Magicard NEO range

* Currently for PC-based computer systems only



Register your device at
PRINTanID.com and
download a copy of the
software which is fully
compatible with your
Magicard NEO printer




MAGiCARDNEO

REGISTER & DOWNLOAD



STEP 1:

Visit <http://PRINTanID.com> to download the PRINTanID software for your PC.




REGISTER & DOWNLOAD



STEP 2:

The Magicard NEO printer must be registered with Magicard in order for customers to be able to receive the download of PRINTanID.

In the box, type the Magicard NEO printer serial number to check the status of the device registration.




REGISTER & DOWNLOAD



NOTE:

Please be aware that the PRINTanID software has been designed only for use in conjunction with Magicard NEO printers.

If the printer serial number indicates the printer is not a NEO model, then customers will not be able to proceed with the download of this software product.




REGISTER & DOWNLOAD



STEP 3:

If the Magicard NEO printer is not registered with Magicard then it must be registered at this point in order to receive the download link for PRINTanID.

Register the printer on PRINTanID.com or at <http://www.magicard.com> in order to proceed with the software download.




REGISTER & DOWNLOAD




STEP 4:

Once the registration status of the Magicard NEO printer is confirmed then the customer will be sent a link to download the PRINTanID package.

Please note, the link will be sent to the email address that was used to register the NEO printer.



REGISTER & DOWNLOAD




STEP 5:

Once customers receive the email, they should click on the link contained therein.

They will be taken to this page from where they can download the .exe file which will run the PRINTanID software on their PC.

Once they have downloaded an unzipped the folder containing the software and associated files then they should follow the instructions for installation.



INSTALLATION



STEP 1:


Extract the file named "Magicard.Bundle.exe" from zip folder.

STEP 2:

Double click on the installer.

The installation of PRINTanID will commence.

Note: If installer is already installed in the system, it will ask you to "Uninstall" or "repair" the software.



INSTALLATION



STEP 3:

When "Magicard will be installed in your system" is displayed, click 'install'.


STEP 4:

The you are asked "Do you need to install this in your computer" click on 'Yes'.


STEP 5:

Check the check box beside "I accept the terms in the License Agreement".

Click on 'next'.




INSTALLATION




STEP 6:

"Website Name" is displayed, click on 'next'.




INSTALLATION



STEP 7:

"Application pool name" is displayed, please click on 'next'.




INSTALLATION




STEP 8:

In "Custom Setup", please click on 'next' to continue.



INSTALLATION



STEP 9:

In "Ready To install MAGiCARD" click on 'install'.

STEP 10:


When you see the message, "Completed the "MAGiCARD Setup Wizard" click 'Finish'.

At this point, "Setup Successful" will be displayed, click on 'close'.


STEP 11:

Open your internet browser and enter: <https://localhost:85>.

You will now see the start page of **PRINTanID**.




FIRST TIME OPERATION




STEP 1:

Start customer set-up by inserting your company name when requested.



FIRST TIME OPERATION




The screenshot shows a web browser window displaying the 'Customer Setup' form for MAGiCARD NEO. The form is titled 'Customer Setup' and includes the following fields:

- Email***: A text input field with a blue envelope icon on the left.
- First Name***: A text input field with a blue person icon on the left.
- Last Name***: A text input field with a blue person icon on the left.
- Contact Number***: A text input field with a blue phone icon on the left.


At the bottom of the form, there are two buttons: '← PREVIOUS' and 'NEXT →'. Below the buttons are three small circular indicators, with the middle one being filled in blue, indicating the current step in the process.

STEP 2:

Insert your contact details into the appropriate boxes.




FIRST TIME OPERATION



STEP 2:

Choose a password (remember, do not make it easy for others to steal your confidential ID card data – take care to make your password unique) and confirm the password to finish the set-up stage.




FIRST TIME OPERATION




STEP 3:

Use your email and the password you chose in the set-up stage to login to your PRINTanID account.



FIRST TIME OPERATION




STEP 4:

Use the simple template editor to create a card template including photographs, logos and personnel details.

Upload existing contact databases, save different templates for different classes of personnel.

PRINTanID and manage your ID card needs with Magicard NEO.




FIRST TIME OPERATION




SUPPORT:

In the event that you need support for either installation or operation of the PRINTanID software, please visit <http://support.magicard.com> and complete the form and one of our world-class technical support team will respond to you and help you solve your issue.



MAGiCARDNEO



TRUSTED, SECURE ID CARD PRINTING

Introducing NEO PrintAnID